



# Quick guide to updating your firmware

---

PUBLISHED - 25 FEB 2021

# Z series

## QUICK GUIDE TO UPDATING THE FIRMWARE

Z 6II



Z 7II



### STEP 1 GET READY

You'll need:



Camera



PC or  
Mac



Memory  
Card

## — **STEP 2** LOCATE THE FIRMWARE [DOWNLOADCENTER.NIKONIMGLIB.COM](http://downloadcenter.nikonimglib.com)

To do this:

Go to 'Service and Support'



Select 'Download Center'



Choose camera then 'Firmware'



Select 'View Download Page'



Accept the Nikon License Agreement and 'Download'.



### STEP 3 THE FIRMWARE FILE

For this stage:

- **Unzip** the download



- **Save** the '.Bin' file to the Memory Card

(do not put the file in a folder)

- **Remove** the memory card from computer.



## STEP 4 READYING THE CAMERA

Moving back to the camera:

- Insert Memory card and press 'Menu'
- Select 'SETUP MENU'
- Scroll down and select 'Firmware version'.



## — STEP 5 INSTALLING THE FIRMWARE

To complete the process:



- Select 'Update' and press 'OK'
- Do not use or turn off while updating
- Once complete, your camera is up to date

Download firmware from [here](#).