Quick guide to updating your firmware

PUBLISHED - 25 FEB 2021

Z series

QUICK GUIDE TO UPDATING THE FIRMWARE

Z 6II



Z 7II



STEP 1 GET READY

You'll need:

Camera

PC or Mac

Memory Card

STEP 2 LOCATE THE FIRMWARE
DOWNLOADCENTER.NIKONIMGLIB.COM

To do this:

Go to 'Service and Support'

↓

Select 'Download Center'

↓

Choose camera then 'Firmware'

↓

Select 'View Download Page'

↓

Accept the Nikon License Agreement and 'Download'.



STEP 3 THE FIRMWARE FILE

For this stage:

- Unzip the download





- Save the '.Bin' file to the Memory Card

(do not put the file in a folder)

- Remove the memory card from computer.



STEP 4 READYING THE CAMERA

Moving back to the camera:



- Insert Memory card and press ‘Menu’
- Select ‘SETUP MENU’
- Scroll down and select ‘Firmware version’.





Download firmware from here.

© NIKON U.K.